


Package Contents


The w4 package includes:

- Power adapter
- Rubber feet
- 2x antennas
- w4 appliance

Rear Panel



Front Panel



Installation

- 1. Attach the rubber feet to the bottom corners of the w4 appliance.
- 2. Fasten the included WiFi antennas to the WiFi labeled SMA connectors.
- 3. Connect an ethernet cable from your Internet modem or router to the port labeled INTERNET.
- 4. Connect an ethernet cable from your management computer or LAN switch to port 1.
- 5. Plug in the 12V power adapter to a power source and connect it to the **DC 12V** power input on the rear panel.
- 6. The device powers automatically. Allow approximately 2 minutes for the system to initialize before continuing with the next steps.

Getting Started

You can manage your appliance via **Command Center** or from the local network.

From Command Center

- 1. Navigate your web browser to https://untangle.com/cmd.
- 2. Log in with your Untangle Command Center account, or click Create Account to set up an account.
- 3. Navigate to the Appliances screen and click Add.
- 4. Enter the Untangle serial number located on the bottom of your appliance.



- 5. Click **Add** to confirm the new appliance.
- 6. Complete the initial setup to begin managing your appliance.

From the local network

- 1. Connect an ethernet cable from your management computer or LAN switch to the LAN port.
- From your management computer, check the network status of your system and confirm that you receive an IPv4 address in the subnet of 192.168.2.0/24 (e.g. 192.168.2.100).
- In a browser, navigate to http://192.168.2.1.
- 4. Follow the steps in your browser to complete the setup.

Warranty

This appliance is covered by a one or three year warranty based on the option chosen at the time of purchase. For a description of the warranty policy visit http://www.untangle.com/refund-return-policy.

Support & Documentation

For Untangle NG Firewall documentation, technical support availability, contact information, and troubleshooting tips visit http://support.untangle.com.